



Designation: D4055 – 04 (Reapproved 2019)

Standard Test Method for Pentane Insolubles by Membrane Filtration¹

This standard is issued under the fixed designation D4055; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon (ϵ) indicates an editorial change since the last revision or reapproval.

1. Scope

1.1 This test method covers the determination of pentane insolubles for particles exceeding 0.8 μm in new and used lubricating oils.

NOTE 1—Pentane insolubles with particle sizes less than 0.8 μm may be studied with appropriate size membrane filters. Particle sizes above or below 0.8 μm can be studied. The precision of this test method has been determined only at 0.8 μm .

1.2 The values stated in SI units are to be regarded as standard. No other units of measurement are included in this standard.

1.3 *This standard does not purport to address all of the safety concerns, if any, associated with its use. It is the responsibility of the user of this standard to establish appropriate safety, health, and environmental practices and determine the applicability of regulatory limitations prior to use.* For specific warning statements, see 7.1, 8.2.1, and Annex A1.

1.4 *This international standard was developed in accordance with internationally recognized principles on standardization established in the Decision on Principles for the Development of International Standards, Guides and Recommendations issued by the World Trade Organization Technical Barriers to Trade (TBT) Committee.*

2. Referenced Documents

2.1 ASTM Standards:²

D4057 Practice for Manual Sampling of Petroleum and Petroleum Products

D4175 Terminology Relating to Petroleum Products, Liquid Fuels, and Lubricants

D4177 Practice for Automatic Sampling of Petroleum and Petroleum Products

¹ This test method is under the jurisdiction of ASTM Committee D02 on Petroleum Products, Liquid Fuels, and Lubricants and is the direct responsibility of Subcommittee D02.06 on Analysis of Liquid Fuels and Lubricants.

Current edition approved Jan. 1, 2019. Published February 2019. Originally approved in 1992. Last previous edition approved in 2013 as D4055 – 04 (2013). DOI: 10.1520/D4055-04R19.

² For referenced ASTM standards, visit the ASTM website, www.astm.org, or contact ASTM Customer Service at service@astm.org. For *Annual Book of ASTM Standards* volume information, refer to the standard's Document Summary page on the ASTM website.

3. Terminology

3.1 Definitions:

3.1.1 *pentane insolubles, in used oil analysis, n*—separated matter resulting when a used oil is dissolved in pentane.

3.1.1.1 *Discussion*—In this test method, the separation is effected by filtration through a membrane.

3.1.2 *used oil, n*—any oil that has been in a piece of equipment (for example, an engine, gearbox, transformer, or turbine) whether operated or not. **D4175**

4. Summary of Test Method

4.1 A sample of new or used lubricating oil is mixed with pentane in a volumetric flask. The oil solution is filtered through an 0.8 μm membrane filter. The flask, funnel, and filter are washed with additional pentane to effect a complete transfer of particulates onto the filter. The filter and its particulates are dried and weighed to give the pentane insolubles.

5. Significance and Use

5.1 Pentane insolubles above 0.8 μm in size may lead to increased wear. This increased wear can lead to premature equipment failure in critical applications.

6. Apparatus

6.1 In the development of this test method, it was noted that variations, particularly with respect to glassware and filter media, can affect the test result significantly.

6.2 When the user of this test method uses an alternate membrane filter, it is incumbent upon them to establish that the alternate filter will give equal results.

6.3 Precision data were established using the apparatus listed and a 0.8 μm filter pore size.

6.4 Membrane Filter.

6.5 Borosilicate Filter Holder.

6.6 Borosilicate Filtering Flask.

6.7 Forceps (plain flat tips, not serrated),

6.8 Wash Bottle equipped with 0.8 μm membranes.

6.9 *Analytical Balance*, capable of weighing with an accuracy of ± 0.1 mg.

6.10 *Vacuum Source*, capable of maintaining a vacuum of 255 mm \pm 50 mm Hg.

6.11 *Oven*, capable of maintaining 90 °C \pm 5 °C.

6.12 *Oven Thermometer*, ASTM Thermometer 1C.

6.13 *Aluminum Foil Weighing Dish*, about 60 mm in diameter.

6.14 *Desiccator*, with calcium chloride.

6.15 *Mechanical Paint Shaker*, three-dimensional.

6.16 *Volumetric Flask*, 100 mL with ground-glass or TFE-fluorocarbon stopper.

6.17 *Ionizing Unit*, insert under or next to balance pan.

7. Reagent

7.1 Pentane, reagent grade or better. (**Warning**—Extremely flammable. Vapors can cause flash fire. See A1.1.)

8. Procedure

8.1 Using either Practice D4057 (manual sampling) or Practice D4177 (automatic sampling), obtain a representative sample of the material to be tested.

8.1.1 *Preparation of Sample and Materials*:

8.1.2 Warm the oil in the original container, if possible, to 60 °C \pm 5 °C. Shake for a minimum of 30 min on the mechanical shaker to resuspend the insolubles uniformly.

NOTE 2—Deviation from this sample preparation will normally result in poor precision. Correct sample size is particularly important.

8.1.3 Weigh 1 g of a representative sample of the oil into a 100 mL volumetric flask to the nearest 0.01 g.

8.1.3.1 Certain oils may require smaller size samples to prevent plugging the membrane. When the 100 mL of the mixture has not passed through the membrane after 2 min, discard the test and repeat with a smaller sample size (\pm 10 %) in the order listed:

0.80	0.33	0.13	0.05
0.64	0.26	0.11	0.04
0.51	0.21	0.09	0.03
0.41	0.17	0.07	0.02

8.1.4 Filter pentane through an 0.8 μ m filter.

8.2 *Preparation of Membrane*:

8.2.1 Wash the membrane with 100 mL of filtered pentane (**Warning**—See 7.1) and place the membrane right side up (8.2.1.1) into individual aluminum weighing dish.

8.2.1.1 *Important*—The top side of the membrane as removed from the manufacturer's container shall be similarly orientated for the duration of the procedure. If the filter is reversed, the results are invalid.

8.2.2 Place the dish into the oven and dry for a minimum of 30 min at 90 °C \pm 5 °C. At the end of the drying period, remove the dish from the oven and cool for a minimum of 30 min in a desiccator containing calcium chloride or some other material that will assure an atmosphere free of moisture and hydrocarbon vapors.

8.2.3 When the membranes have reached equilibrium (about 30 min), weigh the membrane to the nearest 0.1 mg.

8.2.4 Store the aluminum dish in the desiccator until ready for use.

8.3 *Filtration*:

8.3.1 Remove the membrane filter from the weighing dish with the flat forceps and center in the filtering apparatus. Assemble the funnel and clamp.

8.3.2 Fill the volumetric flask containing the sample to the 100 mL mark with filtered pentane. Stopper and shake well. *Immediately* filter the mixture using a vacuum of 255 mm \pm 50 mm Hg (see 8.1.3.1). Rinse the flask and stopper twice with small amounts of filtered pentane, pouring the washings down the sides of the filter funnel. Rinse the walls of the filter funnel with a gentle stream of pentane dispensed from the wash bottle.

8.3.3 Carefully, remove the clamp and funnel. Wash any adhering insolubles from the funnel onto the membrane, using the wash bottle with pentane. Wash the membrane *gently*, particularly the edges, with pentane from the wash bottle. If any sample fails to remain on the membrane, the test must be repeated.

8.3.4 Release the vacuum and carefully remove the membrane with the forceps. Place in the same aluminum weighing dish originally used and dry in the oven and cool in the desiccator as in 8.2.2. Weigh the membrane to the nearest 0.1 mg.

NOTE 3—The use of a semimicro balance for particulates weighing less than 0.0010 g is strongly recommended.

9. Calculation

9.1 Calculate the pentane insolubles content of the oil by membrane filtration as follows:

$$\text{Pentane insolubles, \%} = 100(M_2 - M_1)/S \quad (1)$$

where:

S = mass of sample, g,

M_1 = initial mass of membrane, g, and

M_2 = final mass of membrane and insolubles, g.

10. Report

10.1 Report the percentages of pentane insolubles by membrane filtration as:

pentane insolubles (0.8 μ m) percent weight

10.2 Some new oil chemistry will require determination of a baseline value for the new oil (that is, the blank determination may not be zero).

11. Precision and Bias³

11.1 The precision of this test method as determined by statistical examination of interlaboratory results is as follows:

11.1.1 *Repeatability*—The difference between two test results, obtained by the same operator with the same apparatus under constant operating conditions on identical test material, would in the long run, in the normal and correct operation of the test method, exceed the following values only in one case in twenty:

³ Supporting data have been filed at ASTM International and may be obtained by requesting Research Report RR:D02-1209. Contact ASTM Customer Service at service@astm.org.

$$0.177 X^{2/3}$$

(2)

where:

X = average of two results.

where:

X = average of two results.

11.1.2 *Reproducibility*—The interlaboratory precision (reproducibility) of this test is very poor, and this method of measuring pentane insolubles is unsuitable for the purpose of comparison of interlaboratory results. Additional cooperative studies to improve the precision are planned.

$$0.759 X^{2/3}$$

(3)

11.2 *Bias*—A statement of bias is not applicable since a standard reference material for this property is not available.

12. Keywords

12.1 lubricating oils; membrane filtration; pentane insolubles

ANNEX

(Mandatory Information)

A1. WARNING STATEMENTS

A1.1 Pentane

A1.1.1 **Warning**—Extremely flammable liquid!
Vapors may cause flash fire.
Keep away from heat, sparks, and open flame.
Keep container closed.
Use with adequate ventilation.

Avoid buildup of vapors and eliminate all sources of ignition, especially nonexplosion-proof electrical devices and heaters.

Avoid prolonged breathing of vapor or spray mist.

Avoid prolonged or repeated skin contact.

ASTM International takes no position respecting the validity of any patent rights asserted in connection with any item mentioned in this standard. Users of this standard are expressly advised that determination of the validity of any such patent rights, and the risk of infringement of such rights, are entirely their own responsibility.

This standard is subject to revision at any time by the responsible technical committee and must be reviewed every five years and if not revised, either reapproved or withdrawn. Your comments are invited either for revision of this standard or for additional standards and should be addressed to ASTM International Headquarters. Your comments will receive careful consideration at a meeting of the responsible technical committee, which you may attend. If you feel that your comments have not received a fair hearing you should make your views known to the ASTM Committee on Standards, at the address shown below.

This standard is copyrighted by ASTM International, 100 Barr Harbor Drive, PO Box C700, West Conshohocken, PA 19428-2959, United States. Individual reprints (single or multiple copies) of this standard may be obtained by contacting ASTM at the above address or at 610-832-9585 (phone), 610-832-9555 (fax), or service@astm.org (e-mail); or through the ASTM website (www.astm.org). Permission rights to photocopy the standard may also be secured from the Copyright Clearance Center, 222 Rosewood Drive, Danvers, MA 01923, Tel: (978) 646-2600; http://www.copyright.com/